1.1 Phone overview

1.Technical specifications

imensions (W×D×H): 106.3X46X13.5MM
/eight:with out battery 67 Grams
ithium battery:NOkia 5C
ated capacity:1000Mah
ontinuous standby duration: (Relates to network status) 00 Hours
ontinuous conversation duration: (Relates to network atus) 130 Mins
lease refer to their labels for other data related to the attery and the charger.

2 Getting started

2.1 Installing the SIM cards

emove the back cover and lift battery away. Insert SIM

ard into the SIM card slot lightly.

2.2 Installing T-Flash Card

To install the T-Flash card, open its latch, place its idented side downward, insert the card into the card slot,

nd then close the latch.

To remove the T-flash card, open its latch and ightly press the card inward. The card will automatically op out. Close the latch.

2.1 Charging the Battery

The lithium battery delivered with the mobile phone an be put into use immediately after being unpacked. A ew battery will have maximum performance after the first ree full charge/discharge cycles.

2.2 Linking to the Network

he mobile phone automatically searches for an available etwork.

◆ **Dialing a call to a number in the phonebook**

Enter the phonebook and use the upward and/or ownward direction keys to find the telephone number you ant to call.

ress the Dial key. The mobile phone automatically dials ie chosen telephone number.

◆ **Redialing the last number**

In the standby interface, press the dial key to show the ialed calls.

ress the upward and/or downward direction keys to select number you want to dial and then press the Dial key.

◆ **Adapting volume**

uring a conversation, you can press the Up and/or Down irection keys to tune the sound volume.

◆ **Answering incoming calls**

ress the Dial key or the Left soft key to answer an ıcoming call.

ress the End key to end the current conversation.

o reject an incoming call, press the End key or the Right oft key.

◆ **Using options during a conversation**

Select Options during a conversation to pause, end the ngoing call, originate a new call, browse the phonebook, iew information, set the mute, set the DTMF, or perform ther operations. For details, refer to the menu guide.

2.3 Using the Headset

It would enter headset mode automatically when you ısert headset to the slot. Make sure of inserting it at the ottom of the slot, or you can't use it normally.

3 Input method

This mobile phone provides multiple input methods, ıcluding English input in both upper and lower case, and umeric input method.

3.1 To Shift Entry Methods

ress the # key to switch between input methods.

3.2 Numeric Input

ou can input numbers with the numeric input method. ress a number key to input the corresponding number.

3.3 Inserting a Symbol

Press the * key to enter the **Select symbol** interface, se direction keys to select a symbol you want.

4.1 Call center

Missed Calls: You can view a list of the latest missed calls.

Dialed Calls:You can view the latest dialed calls. Choose dialed calls **and then select a dialed call to delete, save, dial, or edit (or send a short message to it).**

Received Calls:You can view the latest received calls. Choose received calls **and then select a received call to delete, save, dial, or edit (or send a short message to it).**

Rejected calls:A list of calls you've rejected.

Delete all :You can delete the latest call records.

Call Timers

GPRS flow rate

- **Last sent:** Viewing the rate of last session sent
- **Last received:** Viewing the rate of last session received
- **All sent:** Viewing all of the rate of sessions sent
- **All received:** Viewing all of the rate of sessions received
- **Reset counter:** Clearing all rates**.**

4.2 Multimedia

Camera

This function enables you take a picture you want. Roll the phone to align the camera to the picture and then press OK key, which the picture will be stored in the album.

Select "option" and you can set some paramount of photo and camera, and scan the pictures you've taken in gallery and view the storage status.

.nalog TV

'ideo recorder

his function enables you to record dynamic pictures. .dapt the VCR to the scene or the figure, the press OK to art or pause recording. Press STOP to end recording, and ıe phone would save the file automatically.

'ideo player

his function enables you play, send, rename, delete, delete ll files, rank or save your video and movies.

mage viewer

his function enables you view, edit, slide show, use as, :nd, rename, delete, delete all files, rank and save about our pictures.

.udio Player

he audio player provides four buttons: Play or Pause, Stop, ack, and Forward which are corresponding to the up irection key, down direction key, left direction key and ght direction key. The audio player supports MP3, ormats. Press # key and * key to increase or decrease olume.

.ecorder

he phone support WAV. The recording file you stopped ould be stored in file list automatically. You can select orage location as needed. The path is ıultimedia>recorder>option>storage location>Udisk/ ıemory card.

M Radio

our phone is equipped with an FM radio. You can use the

ppication as a traditional FM radio with automatic tuning nd saved channels. Press # key and * key to increase or ecrease volume.

ile manager

he phone provides a certain space for users to manage les and supports the T-Flash card. The capacity of the -Flash card is selectable. You can use the file manager to onveniently manage various directories and files on the hone and the T-Flash card.

hoose **File manager** to enter the root directory of the iemory. The root directory will list the default folders, ew folders and user files. When the mobile phone is owered on for the first time or when you have not changed ie directory, the root directory contains the default folders nly.

ou can use this function to format all the data in the iemory. The system will re-create a default folder. The ormatted data cannot be recovered. Therefore, think twice efore using the formatting function.

4.3 Phonebook

he mobile phone can store up to 500 telephone numbers.

4.4 User profiles

he mobile phone provides multiple user profiles, so that ou can customize some settings to adapt to the specific vents and environments.

ustomize the user profiles according to your preference nd then activate the user profiles. The user profiles fall nto five scenarios: **General**, **Meeting**, **Outdoor**, **Indoor**

ıd **Silent.**

elect option, and you can perform the following perations: Activate, Settings and Rename.

lote: In standby state, hold the # key to switch to the mute ıode. To switch back to the original mode, hold the # key gain.

4.5 Messages

` the short message memory is full, a blinking SMS icon ppears on the top of the screen. To normally receive short ıessages, you need to delete some of the existing short ıessages.

4.6 Tools

.larm

hree alarm clocks are set but deactivated by default. You an activate one, multiple or all of them as needed. For ach alarm clock, the ringing date and the ringing time can e set. When the preset alert time is up, the mobile phone ives off an alert tone whereas the current date and time links on the screen. Select **Stop** to stop the ring or **Snooze**) temporarily stop the ring. If you select **Snooze**, the alarm lock will ring four minutes later.

'alendar

)nce you enter this menu, there is a monthly-view calendar)r you to keep track of important appointments, etc. Days ·ith events entered will be marked

luetooth
-Book reader
alculator
old down the '*'key to get the decimal point. Confirm
ith the **OK** key or the left soft key.
ote: *This calculator provides limited precision and is only pplicable to simple arithmetic calculation.*

World clock
Torch
STK

4.7Settings

ual SIM Settings

- **Dual-SIM:** Dual-SIM refers to two SIM card slots, and the two cards can standby at the same time or set one of them to display on the idle screen.

all Setup

- **Network selection:** Set Network selection mode to utomatic or Manual. Automatic is recommended. When etwork selection mode is set to Automatic, the mobile hone will prefer the network where the SIM card is gistered. When Network selection mode is set to Manual, ou need to select the network operator's network where e SIM card is registered.
- **Call waiting**

- Activate: After you choose Activate, the mobile phone will contact the network. A moment later, the network will make a response and send a message

to acknowledge your operation. If the call waiting function is activated, the network will alert you and the mobile phone screen will display the incoming call number if others are calling you while you are already in a conversation.

- Deactivate: If you choose Deactivate, the network will not alert you when others are calling you while you are already in a conversation.
- Query status: Query the network to obtain the current call waiting status.

- **Hide ID:** When you call someone, he or she can't find out your number if you enable this function.
- **Line selection:** Switch to Line 1 or Line 2. By default, Line 1 is used.

'ote: If you choose Line 2, dialing may fail. This depends n the implementation of the network operator.

hone Settings

- **Time and date**: Set time, date, time format and date display type.
- **Language**: Select the display language for the mobile phone.

'isplay

elect images and set them as wallpaper and idle display. 'ou can set duration of backlight and keypad light.

ecurity Settings

his function provides you with related settings about afety use. To set the SIM1 lock, you need to input the PIN. 'ou can set the SIM lock only after inputting the correct

IN. If you set SIM1 lock to On, you need to input the PIN
ach time you power on the mobile phone. In the case you
nput a wrong PIN for three consecutive times, you need to
nput the PIN Unblocking Key (PUK). The PUK is used to
nlock and change the locked PIN. To obtain the PUK,
ontact the network operator. Fixed dial requires the SIM
ard's support and the network operator's support. When
ıe fixed dial function is activated, you can dial only the
umbers in the fixed dial list. To activate the fixed dial
ınction, you need to input the PIN2. Barred dial requires
IM card's support, you can activate or deactivate barring
f some or all calls. Phone lock enables you to lock/unlock
ıe phone. Input password to switch on or off the phone.
assword is required when the phone is locked. The
assword is 4 to 8 digits. Keypad lock enables you to
ock/unlock the keypad. Setting the auto locking time that
s, 30s, 1min or 5mins is available. The keypad will be
ıto locked with no operation during the period.

estore factory settings

estore settings: Choose Phone Settings > Restore settings
restore the factory settings. Input the phone lock code
nd then select OK or press the Left soft key.

lote: The initial phone lock code is 1234.

4.7 ICE SMART ZONE

ace book,
ox man,
ISN
ahoo

witter
oogle
. game named Box man is embedded in the phone, you an refer to ‘Help’ option embedded in the phone for peration.
ames settings: You can turn on or turn off Audio or ibration and modify volume as needed.

4.8 Service

his function enables you to view the internet. Your phone ill ask you with existed way. You can start to view only y starting corresponding way. You can store a website of ome page in each way. The home page will be first iewed when using WAP explore. And you can add, edit, elete or send bookmarks. The websites you’ve visited are sually stored in Histories. Moreover, you are able to set ome paramount of WAP settings as needed.